



ENGLISH

1. Power Button
2. Play/Pause
3. Volume Down
4. Volume Up
5. Microphone
6. USB-C
7. AUX
8. LED



CONNECT AND USE

- 1 Charge your JOY SPEAKER for a least 10 minutes before use.
- 2 Hold the power button for 2 seconds to turn the speaker on. The LED will flash white and the speaker is ready to pair.
- 3 Select "Happy Plugs Joy Speaker" on your phone/device to pair. Your speaker is now ready to use.



DISCONNECT A DEVICE

- 1 When the speaker is connected to a device double press the power button to disconnect.

The speaker is now disconnected and ready to pair to a new device. Just follow the "Connect and use" steps.



STEREO SPEAKER MODE

- 1 Turn both speaker on, press and hold the play button on one of the speakers until you hear a sound.
- 2 Check the indicator lights. Main speaker (left channel) will have a flashing light, unless its connected to your phone/device. The other (right channel) a solid light.

To disable stereo mode, press and hold the play button on one of the speakers for 2 seconds until you hear a sound.



BUTTON CONTROLS



- | | |
|-----|-----------------|
| 2 s | On / Off |
| 8 s | Reset |
| x 1 | Bluetooth / AUX |



- | | |
|-----|------------------------|
| x 1 | Play / Pause |
| x 1 | Answer Call / End Call |
| x 2 | Call Latest Number |
| 2 s | Reject Incoming Call |
| 2 s | Stereo Speaker Mode |



- | | |
|-----|----------------|
| x 1 | Volume Up |
| 2 s | Next Track |
| x 1 | Volume Down |
| 2 s | Previous Track |



TROUBLESHOOTING

The speaker doesn't turn on?

Charge your speaker.

The speaker doesn't turn off or respond?

Hold power button for 8 seconds to reset the speaker and turn it off.

I can't connect to the speaker?

Disconnect other connected devices and try again.

Full instructions & FAQ available at:
help.happyplugs.com